


POWER STEERING OIL PUMP

CAUTION:

When changing retainer spring, use the same part number retainer spring as the former retainer spring.




SST979A

Pre-disassembly Inspection

The power steering oil pump should be disassembled only if any of the following conditions are observed.


- Oil leak at the following points



SST984A

- Deformed or damaged pulley

Oil Pump Installation



SST221A

- After installing oil pump, adjust belt tension. Refer to MA section.

SERVICE POWER STEERING OIL PUMP (S.D.S.)

Disassembly

CAUTION:

- The parts which can be disassembled are strictly limited. Never disassemble parts other than the specified ones.
- Disassembly should be performed in a place as clean as possible.
- Do not use a rag. Be sure to use nylon or paper cloth.
- When disassembling and reassembling, do not allow any foreign material to enter or contact any parts.

1. Remove rear cover upward.

- Be careful not to lose the 2 pins as they often stick to rear cover.

2. Carefully remove cam ring, rotor and vanes.

3. Remove snap ring, then draw pulley shaft out.


- Be careful not to drop pulley shaft.
- Be careful not to damage rotor. If damaged, replace as a pump assembly.

4. Remove front side plate.


- Do not damage inside of front housing.

5. Remove oil seal from front housing.

- Be careful not to damage front housing.



6. Remove connector bolt.
7. Remove connector.
- Be careful not to drop spool valve.



8. Remove suction pipe, then remove O-ring.

Inspection

Clean all disassembled parts (inside pump) with suitable cleaning solvent.

INSIDE PARTS

If there are any cracks or flaws, replace pump assembly.

PULLEY AND PULLEY SHAFT

- If pulley is cracked or deformed, replace it.
- If an oil leak is observed around pulley shaft oil seal, replace it.
- If serration of pulley or pulley shaft is deformed or worn, replace it.

OIL PRESSURE SWITCH (Non-turbocharged model)

High-pressure side hydraulic line pressure kPa (kg/cm ² , psi)	Operation
Increasing to 1,961 - 2,942 (20 - 30, 284 - 427)	Turn ON
Decreasing to Approx. 981 - 2,942 (10 - 30, 142 - 427)	Turn OFF

Refer to "Hydraulic System Check" in "POWER STEERING SYSTEM - Checking".